4G multifunctional GPS Tracker



GPT45 User Manual

Application: Cold Chain Monitoring、 Automotive Risk Control、 Logistics Transportation

| -, | Product Features | 3 |
|----|----------------------------|---|
| | 1.1 Performance | 3 |
| | 1.2 Specification | 4 |
| 二、 | Components and Accessories | 5 |
| | 2.1 Components | 5 |
| | 2.2 Accessories | 5 |
| Ξ、 | User Manual | 6 |
| 四、 | TEMP probe Extension | 7 |
| 五、 | Warranty Rules | 8 |
| | After sales | 8 |

—、Product Features

- 1.1 Performance
- Globally support viarious satellite positioning
- GEO-Fence Alarm; In or out of setting area
- Long standby
 - 18650 Type Rechargeable lithium battery
- Temperature Alarm
 Built-in Temperature sensor
- Crash/Falling/Vibration/Speed Alarm
 Built-in accelerometer
- Detecting Opening box / door Alarm
 Built-in Light sensor
- ■(Customization)Expansion

Temperature and Humidity Sensor Probes

USB interface


TYPE-C USB and UART port all in one

- APP and web platform queries
- Provide current air pressure data of the device (customized)
- Waterproof IP65

1.2 Specification

| Demension | 95(L)x55.5(W)x22.7(H) mm | | |
|------------------------|---|--|--|
| LED | GPS (Blue), GSM /LTE(Red) | | |
| Battery | 2600mAh | | |
| Weight | 106 g | | |
| Temperature/Humidity | -20°C~75°C/20%~90%RH | | |
| Antenna | Built-in GSM/LTE antenna, ceramic GPS antenna | | |
| Network Type | LTE-FDD/LTE-TDD/GSM | | |
| GNSS Band | BDS/GPS/GLONASS | | |
| GSM Band | GSM850/EGSM900/DCS1800/PCS1900 | | |
| LTE Band | LTE-FDD:B1/B2/B3/B4/B5/B7/B8/B12/B13/ B17/B18/B19 /B20/B25/B26/B28/B66 LTE-TDD :B34/B38/B39/B40/B41 | | |
| Hot/warm/cold fix time | <3s,<26s,<35s ;(Toward sky) | | |
| USB Interface | Type-C | | |
| SIM Card | Mini-SIM | | |

Components and Accessories 2.1 Components



Key Description :

Press and hold the power button for 8 seconds to turn on/off;

Factory adjustable but not shutdown version

LED indicators(network status indicator)/blue (GPS status indicator)

SIM Card: Mini-SIM

2.2 Accessories

USB charging cable, user manual

5

三、User Manual

3.1 Open the box and check if the device is correct and has all accessories, otherwise please contact your dealer.



Install SIM card first (Chip facing down, Norch facing in) Power on the tracker.

3.2 Query data on the Cellphone APP and Web



Web:www.keelin.com.cn

3.3 New user click "Register", Login the account

四、TEMP probe Extension

Built-in temperature sensor, optional temperature/humidity probe



五、Warranty Rules

- 5.1 Special statement
- 1) Technology change without notice.
- 2) If the product color and appearance change, the actual product shall prevail.
- 3) Please keep the warranty card, show

it with the original purchase receipts during the warranty.

5.2 Warranty period

One year warranty from the purchase date if it is not artificially damaged.

5.3 After sales

Any of the following circumstances is not

covered by the warranty, but may be

appropriate to pay repair:

- 1) More than the warranty period.
- 2) Unauthorized removal or repair damaged.
- 3) Damage caused by improper installation, use, maintenance, custody.
- 4) Damage caused by force majeure.

| Maintenance Records | | | | | | | |
|---------------------|-------------|---------|-----------------|----------|--|--|--|
| Date | Description | Records | completion Date | Engineer | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |